

## SIP-Accessories



**AVF -1**  
**Area View Finder**

View Finder for the SIP Series detector, used to see what is in the SIP detection zones, enabling masking and range reduction



**AWT -3**  
**Area Walk Tester**

Walk Tester for the SIP Series of detectors. Used to test correct range and functionality



**SIP-AT**  
**SIP Adjustment Tools**

Complete SIP Set up kit Including AWT-3 and AVF-1



**LRP/SIP – PB**  
**LRP/SIP Series Pole Mount Bracket**

Pole Mount Bracket for SIP Series enabling easy mounting on various sized camera poles.



**SIP – MINIHOOD**

Sun/Snow Shield for  
SIP-3020/4010/404

Sun and Snow Shield for SIP-3020 Series, SIP-4010 Series and SIP-404 Series.



**SIP – MIDTHOOD**

Sun/Snow Shield for  
SIP-5030/100

Sun and Snow Shield for the SIP-5030 and SIP-100.



**SIP – HU**

Heating Unit

Heater for the SIP hardwired units.  
Power to SIP should be 22-26VAC.